



# The Garmin GNS-430

## The Basics





To enter in a frequency:

1. Press the PUSH C/V knob to assure the standby com frequency is highlighted. Push the knob again to highlight the standby VLOC frequency.
2. Use the BIG knob on the left of the unit (outside knob) to change the BIG numbers in the highlighted area
3. Use the SMALL knob on the left of the unit (inside knob) to change the SMALL numbers in the highlighted area
4. Press the button immediately to the left of the display to move the new frequency from the standby position to the active position.



To go direct to an airport:

1. Press the  button on the right hand side of the GPS
2. Enter the airport identifier—turn the small knob on the right 1 click to the right, a K should appear in the highlighted area. Turn the BIG knob on the right 1 click to the right to move the cursor to the next space. Enter the appropriate letter using the small knob, and repeat as above. Nearly all airport ID's in the continental US start with a K.
3. Press the ENT key TWICE after you have entered the ID
4. To change the scale of the GPS map, use the  button